

Link do produktu: <https://inforolnik.pl/oring-2-x-12mm-zetor-974516-p-21200.html>



ORing 2 x 12mm Zetor 974516

Cena w sklepie online **0,30 zł**

Numer katalogowy **S.8965**

Opis produktu

Numery porównawcze: 974516

Zastosowanie

Kliknij i zobacz inne części które również pasują do : [Case IH 238 \(Industrial\)](#)[Case IH 248 \(Industrial\)](#)[Case IH 258 \(Industrial\)](#)[Case IH 268 \(Industrial\)](#)[Case IH 288 \(Industrial\)](#)[Case IH 3210 \(3200 Utility Series \)](#)[Case IH 3220 \(3200 Utility Series \)](#)[Case IH 3230 \(32 Series\)](#)[Case IH 385 \(85 Series\)](#)[Case IH 395 \(95 Utility Series \)](#)[Case IH 4210 \(4200 Utility Series\)](#)[Case IH 4220 \(4200 Utility Series\)](#)[Case IH 4230 \(4200 Utility Series\)](#)[Case IH 4240 \(4200 Utility Series\)](#)[Case IH 454 \(International\)](#)[Case IH 474 \(International\)](#)[Case IH 475 \(International\)](#)[Case IH 484 \(International\)](#)[Case IH 485 \(85 Series\)](#)[Case IH 485XL](#)[Case IH 495 \(95 Utility Series \)](#)[Case IH 495XL](#)[Case IH 574 \(74 Series\)](#)[Case IH 584 \(84 Series\)](#)[Case IH 585 \(85 Utility Series\)](#)[Case IH 585XL](#)[Case IH 595 \(95 Utility Series \)](#)[Case IH 595XL](#)[Case IH 674 \(Utility Series\)](#)[Case IH 684 \(84 Series\)](#)[Case IH 685 \(85 Series\)](#)[Case IH 685XL](#)[Case IH 695 \(95 Utility Series \)](#)[Case IH 695XL](#)[Case IH 784 \(84 Series\)](#)[Case IH 784 \(International\)](#)[Case IH 785 \(85 Series\)](#)[Case IH 785 \(International\)](#)[Case IH 785XL](#)[Case IH 795 \(95 Utility Series \)](#)[Case IH 884 \(84 Series\)](#)[Case IH 885 \(85 Series\)](#)[Case IH 885XL](#)[Case IH 895 \(95 Utility Series \)](#)[Case IH 895XL](#)[Case IH 995 \(95 Utility Series \)](#)[Case IH CX100 \(CX Series\)](#)[Case IH CX50 \(CX Series\)](#)[Case IH CX60 \(CX Series\)](#)[Case IH CX70 \(CX Series\)](#)[Case IH CX80 \(CX Series\)](#)[Case IH CX90 \(CX Series\)](#)[Case IH Hydro 84 \(Hydro Static Drive Tractors\)](#)[Case IH Hydro 86 \(Hydro Static Drive Tractors\)](#)[Case IH MX100C](#)[Case IH MX80C](#)[Case IH MX90C](#)[McCormick CX100 \(CX Series\)](#)[McCormick CX50 \(CX Series\)](#)[McCormick CX60 \(CX Series\)](#)[McCormick CX70 \(CX Series\)](#)[McCormick CX80 \(CX Series\)](#)[McCormick CX90 \(CX Series\)](#)[Zetor 3320 \(UR1 Series\)](#)[Zetor 3321 \(UR1 Series\)](#)[Zetor 3340 \(UR1 Series\)](#)[Zetor 3341 \(UR1 Series\)](#)[Zetor 4320 \(UR1 Series\)](#)[Zetor 4321 \(UR1 Series\)](#)[Zetor 4340 \(UR1 Series\)](#)[Zetor 4341 \(UR1 Series\)](#)[Zetor 5211 \(UR1 Series\)](#)[Zetor 5213 \(UR1 Series\)](#)[Zetor 5243 \(UR1 Series\)](#)[Zetor 5245 \(UR1 Series\)](#)[Zetor 5320 \(UR1 Series\)](#)[Zetor 5321 \(UR1 Series\)](#)[Zetor 5340 \(UR1 Series\)](#)[Zetor 5340H](#)[Zetor 5341 \(UR1 Series\)](#)[Zetor 6211 \(UR1 Series\)](#)[Zetor 6245 \(UR1 Series\)](#)[Zetor 6320 \(UR1 Series\)](#)[Zetor 6321 \(UR1 Series\)](#)[Zetor 6340 \(UR1 Series\)](#)[Zetor 6341 \(UR1 Series\)](#)[Zetor 7211 \(UR1 Series\)](#)[Zetor 7245 \(UR1 Series\)](#)[Zetor 7245H](#)[Zetor 7320 \(UR1 Series\)](#)[Zetor 7321 \(UR1 Series\)](#)[Zetor 7340 \(UR1 Series\)](#)[Zetor 7341 \(UR1 Series\)](#)[Zetor 7711 \(UR1 Series\)](#)[Zetor 7745 \(UR1 Series\)](#)