

Link do produktu: <https://inforolnik.pl/przelacznik-niskiego-cisnienia-case-ih-ford-new-holland-82027898-82036401-84419250-p-12525.html>



Przełącznik niskiego ciśnienia Case IH Ford New Holland 82027898 82036401 84419250

Cena w sklepie online **318,00 zł**

Numer katalogowy **S.106654**

Opis produktu

Niskiego ciśnienia Numery porównawcze: 82027898 82036401 84419250

Zastosowanie

Kliknij i zobacz inne części które również pasują do : [Case IH MAGNUM 250 - TMR](#)[Case IH MAGNUM 280 - CVT TMR](#)[Case IH MAGNUM 280 - TMR](#)[Case IH MAGNUM 310](#)[Case IH MAGNUM 310 - TMR](#)[Case IH MAGNUM 340](#)[Case IH MAGNUM 340 - ROWTRAC](#)[Case IH MAGNUM 380 - CVT](#)[Case IH Maxxum 100 \(Maxxum Series\)](#)[Case IH Maxxum 110 \(Maxxum Series\)](#)[Case IH Maxxum 115 \(Maxxum Series\)](#)[Case IH Maxxum 120 \(Maxxum Series\)](#)[Case IH Maxxum 125 \(Maxxum Series\)](#)[Case IH Maxxum 130 \(Maxxum Series\)](#)[Case IH MAXXUM 140](#)[Case IH MXU100 \(MXU Series\)](#)[Case IH MXU110 \(MXU Series\)](#)[Case IH MXU115 \(MXU Series\)](#)[Case IH MXU125 \(MXU Series\)](#)[Case IH MXU135 \(MXU Series\)](#)[Case IH OPTUM 270 CVX](#)[Case IH OPTUM 300 CVX](#)[Case IH Puma 115 \(Puma Series\)](#)[Case IH Puma 125 \(Puma Series\)](#)[Case IH Puma 130 \(Puma Series\)](#)[Case IH Puma 140 \(Puma Series\)](#)[Case IH Puma 145 \(Puma Series\)](#)[Case IH Puma 155 \(Puma Series\)](#)[Case IH PUMA 160](#)[Case IH Puma 165 \(Puma Series\)](#)[Case IH Puma 170 \(Puma Series\)](#)[Case IH Puma 180 \(Puma Series\)](#)[Case IH Puma 185 \(Puma Series\)](#)[Case IH Puma 195 \(Puma Series\)](#)[Case IH Puma 200 \(Puma Series\)](#)[Case IH Puma 210 \(Puma Series\)](#)[Case IH Puma 215 \(Puma Series\)](#)[Case IH Puma 225 \(Puma Series\)](#)[Ford New Holland T1804](#)[Ford New Holland T2104](#)[Ford New Holland T2304](#)[Ford New Holland T6.120 \(T6 Series\)](#)[Ford New Holland T6.140 \(T6 Series\)](#)[Ford New Holland T6.150 \(T6 Series\)](#)[Ford New Holland T6.155 \(T6 Series\)](#)[Ford New Holland T6.160 \(T6 Series\)](#)[Ford New Holland T6.165 \(T6 Series\)](#)[Ford New Holland T6.175 \(T6 Series\)](#)[Ford New Holland T6010 - DELTA](#)[Ford New Holland T6010 - PLUS](#)[Ford New Holland T6010 \(T6000 Series\)](#)[Ford New Holland T6020 - DELTA](#)[Ford New Holland T6020 - ELITE](#)[Ford New Holland T6020 - PLUS](#)[Ford New Holland T6020 \(T6000 Series\)](#)[Ford New Holland T6030 - DELTA](#)[Ford New Holland T6030 - ELITE](#)[Ford New Holland T6030 - PLUS](#)[Ford New Holland T6030 - POWER COMMAND](#)[Ford New Holland T6030 - RANGE COMMAND](#)[Ford New Holland T6030 \(T6000 Series\)](#)[Ford New Holland T6040 - ELITE](#)[Ford New Holland T6040 \(T6000 Series\)](#)[Ford New Holland T6050 - DELTA](#)[Ford New Holland T6050 - ELITE](#)[Ford New Holland T6050 - PLUS](#)[Ford New Holland T6050 - POWER COMMAND](#)[Ford New Holland T6050 - RANGE COMMAND](#)[Ford New Holland T6050 \(T6000 Series\)](#)[Ford New Holland T6060 - ELITE](#)[Ford New Holland T6060 \(T6000 Series\)](#)[Ford New Holland T6070 - ELITE](#)[Ford New Holland T6070 - PLUS](#)[Ford New Holland T6070 - POWER COMMAND](#)[Ford New Holland T6070 - RANGE COMMAND](#)[Ford New Holland T6070 \(T6000 Series\)](#)[Ford New Holland T6080 - POWER COMMAND](#)[Ford New Holland T6080 - RANGE COMMAND](#)[Ford New Holland T6080 \(T6000 Series\)](#)[Ford New Holland T6090 - POWER COMMAND](#)[Ford New Holland T6090 - RANGE COMMAND](#)[Ford New Holland T7.165 - CLASSIC](#)[Ford New Holland T7.165S - CLASSIC](#)[Ford New Holland T7.170 - AUTOCOMMAND](#)[Ford New Holland T7.170 - POWER COMMAND](#)[Ford New Holland T7.170 - RANGE COMMAND](#)[Ford New Holland T7.175](#)[Ford New Holland T7.175 - AUTOCOMMAND](#)[Ford New Holland T7.175 - CLASSIC](#)[Ford New Holland T7.175 - SIDEWINDER I](#)[Ford New Holland T7.185 - AUTOCOMMAND](#)[Ford New Holland T7.185 - POWER COMMAND](#)[Ford New Holland T7.185 - RANGE COMMAND](#)[Ford New Holland T7.190](#)[Ford New Holland T7.190 - AUTOCOMMAND](#)[Ford New Holland T7.190 - CLASSIC](#)[Ford New Holland T7.190 - SIDEWINDER I](#)[Ford New Holland T7.195S - CLASSIC](#)[Ford New Holland T7.200 - AUTOCOMMAND](#)[Ford New Holland T7.200 - POWER COMMAND](#)[Ford New Holland T7.200 - RANGE COMMAND](#)[Ford New Holland T7.210 - AUTOCOMMAND](#)[Ford New Holland T7.210 - CLASSIC](#)[Ford New Holland T7.210 - POWER COMMAND](#)[Ford New Holland T7.210 - RANGE COMMAND](#)[Ford New Holland T7.210 - SIDEWINDER I](#)[Ford New Holland T7.210 \(T7 Series\)](#)[Ford New Holland T7.215S - CLASSIC](#)[Ford New Holland T7.220 - AUTOCOMMAND](#)[Ford New Holland T7.220 \(T7 Series\)](#)[Ford New Holland T7.225 - AUTOCOMMAND](#)[Ford New Holland T7.230](#)[Ford New Holland T7.230 - AUTOCOMMAND](#)[Ford New Holland T7.230 - CLASSIC](#)[Ford New Holland T7.230 - SIDEWINDER I](#)[Ford New Holland T7.235 - AUTOCOMMAND](#)[Ford New Holland T7.235 \(T7 Series\)](#)[Ford New Holland T7.245](#)[Ford New Holland T7.245 - AUTOCOMMAND](#)[Ford New Holland T7.245 - CLASSIC](#)[Ford New Holland T7.245 - SIDEWINDER I](#)[Ford New Holland T7.250 - AUTOCOMMAND](#)[Ford New Holland T7.250 \(T7](#)

Account for EURO PAYMENTS:

PL78 1140 2004 0000 3812 0242 0461

Bic (IBAN) : BREXPLPWMBK

[Series\)Ford New Holland T7.260 - AUTOCOMMANDFord New Holland T7.260 - CLASSICFord New Holland T7.260 - SIDEWINDER II](#)
[Ford New Holland T7.260 \(T7 Series\)Ford New Holland T7.270 - AUTOCOMMANDFord New Holland T7.275 - AUTOCOMMAND](#)
[Ford New Holland T7.290 - AUTOCOMMANDFord New Holland T7.315 - AUTOCOMMANDFord New Holland T7030 \(T7000 Series\)](#)
[Ford New Holland T7040 \(T7000 Series\)Ford New Holland T7050 \(T7000 Series\)Ford New Holland T7060 \(T7000 Series\)Ford](#)
[New Holland T8.275Ford New Holland T8.300Ford New Holland T8.320Ford New Holland T8.330Ford New Holland T8.350Ford](#)
[New Holland T8.360Ford New Holland T8.380Ford New Holland T8.390Ford New Holland T8.410Ford New Holland T8.420Ford](#)
[New Holland TS100AFord New Holland TS110AFord New Holland TS115 \(TS Series\)Ford New Holland TS125AFord New Holland](#)
[TS130AFord New Holland TS135ASteyr 4100 Profi \(Profi Series\)Steyr 4110 PROFISTeyr 4115 Profi \(Profi Series\)Steyr 4120](#)
[PROFISTeyr 4125 PROFISTeyr 4130 PROFISTeyr 4135 PROFISTeyr 4145 PROFISTeyr 6115 Profi \(Profi Series\)Steyr 6125 Profi](#)
[\(Profi Series\)Steyr 6130CVTSteyr 6135 Profi \(Profi Series\)Steyr 6140 PROFISTeyr 6145 PROFISTeyr 6145CVTSteyr 6150CVT](#)
[Steyr 6160CVTSteyr 6165CVTSteyr 6170CVTSteyr 6175CVTSteyr 6185CVTSteyr 6200CVTSteyr 6205CVTSteyr 6215CVTSteyr](#)
[6220CVTSteyr 6230CVTSteyr 6240 CVTSteyr 6250 TERRUS CVT](#)