

Link do produktu: <https://inforolnik.pl/przelacznik-niskiego-cisnienia-case-ih-jcb-111267c2-111267c3-111267c4-1-1666-442183c1-30926813-p-12517.html>



Przełącznik niskiego ciśnienia Case IH JCB 111267C2 111267C3 111267C4 1-1666 442183C1 30/926813

Numer katalogowy

S.106641

Opis produktu

Niskiego ciśnienia Numery porównawcze: 111267C2 111267C3 111267C4 1-1666 442183C1 30/926813

Zastosowanie

Kliknij i zobacz inne części które również pasują do : [Case IH 1055 \(55 Series\)](#)[Case IH 1056 \(56 Series\)](#)[Case IH 1255 \(55 Series\)](#)[Case IH 1440](#)[Case IH 1455 \(55 Series\)](#)[Case IH 1460](#)[Case IH 1480](#)[Case IH 1486 \(86 Series\)](#)[Case IH 1586 \(86 Series\)](#)[Case IH 1620 \(Combine - Axle Flow Series\)](#)[Case IH 1666 \(Combine - Axle Flow Series\)](#)[Case IH 1670 \(Combine - Axle Flow Series\)](#)[Case IH 1680 \(Combine - Axle Flow Series\)](#)[Case IH 1688 \(Combine - Axle Flow Series\)](#)[Case IH 1844 \(Combine - Axle Flow Series\)](#)[Case IH 2055 \(Combine - Axle Flow Series\)](#)[Case IH 3488 \(30 Series\)](#)[Case IH 3688 \(30 Series\)](#)[Case IH 5088 \(50 Series\)](#)[Case IH 585 \(85 Utility Series\)](#)[Case IH 585XL](#)[Case IH 595 \(95 Utility Series \)](#)[Case IH 595XL](#)[Case IH 685 \(85 Series\)](#)[Case IH 685XL](#)[Case IH 695 \(95 Utility Series \)](#)[Case IH 785 \(85 Series\)](#)[Case IH 785 \(International\)](#)[Case IH 795 \(95 Utility Series \)](#)[Case IH 856 \(56 Series\)](#)[Case IH 885 \(85 Series\)](#)[Case IH 885XL](#)[Case IH 895 \(95 Utility Series \)](#)[Case IH 9150 \(9100 Series\)](#)[Case IH 955 \(55 Series\)](#)[Case IH 956 \(56 Series\)](#)[Case IH 985 \(85 Series\)](#)[Case IH 995 \(95 Utility Series \)](#)[Massey Ferguson 27](#)[Massey Ferguson 29](#)[Massey Ferguson 31 \(Industrial Tractors\)](#)