

Link do produktu: <https://inforolnik.pl/przelacznik-wysokocisnieniowy-case-ih-deutz-fahr-ford-new-holland-539069r1-539069r2-a65779-a76253-71190643-72506491-72506492-86000537-86000573-897074-p-12533.html>



# Przełącznik wysokociśnieniowy Case IH Deutz-Fahr Ford New Holland 539069R1 539069R2 A65779 A76253 71190643 72506491 72506492 86000537 86000573 897074

Numer katalogowy

**S.106649**

## Opis produktu

Gwint 7/16 x 20 Numery porównawcze: 539069R1 539069R2 A65779 A76253 71190643 72506491 72506492 86000537 86000573 89707448

## Zastosowanie

Kliknij i zobacz inne części które również pasują do : [Case IH 1055 \(55 Series\)](#)[Case IH 1056 \(56 Series\)](#)[Case IH 1255 \(55 Series\)](#)[Case IH 1394 \(94 Series\)](#)[Case IH 1455 \(55 Series\)](#)[Case IH 1494 \(94 Series\)](#)[Case IH 1594 \(94 Series\)](#)[Case IH 1620 \(Combine - Axle Flow Series\)](#)[Case IH 1666 \(Combine - Axle Flow Series\)](#)[Case IH 1670 \(Combine - Axle Flow Series\)](#)[Case IH 1680 \(Combine - Axle Flow Series\)](#)[Case IH 1688 \(Combine - Axle Flow Series\)](#)[Case IH 1844 \(Combine - Axle Flow Series\)](#)[Case IH 1896 \(1000 Series\)](#)[Case IH 2055 \(Combine - Axle Flow Series\)](#)[Case IH 2096 \(2000 Series\)](#)[Case IH 2294 \(94 Series\)](#)[Case IH 585 \(85 Utility Series\)](#)[Case IH 595 \(95 Utility Series \)](#)[Case IH 685 \(85 Series\)](#)[Case IH 695 \(95 Utility Series \)](#)[Case IH 785 \(85 Series\)](#)[Case IH 785 \(International\)](#)[Case IH 795 \(95 Utility Series \)](#)[Case IH 856 \(56 Series\)](#)[Case IH 885 \(85 Series\)](#)[Case IH 895 \(95 Utility Series \)](#)[Case IH 955 \(55 Series\)](#)[Case IH 956 \(56 Series\)](#)[Case IH 985 \(85 Series\)](#)[Case IH 995 \(95 Utility Series \)](#)[David Brown 1394 \(94 Series\)](#)[David Brown 1490 \(90 Series\)](#)[David Brown 1494 \(94 Series\)](#)[David Brown 1594 \(94 Series\)](#)[Deutz-Fahr 6250 VFD](#)[Deutz-Fahr 6260 VFD](#)[Deutz-Fahr 6275 F](#)[Deutz-Fahr DX3.30 \(DX3 Series\)](#)[Deutz-Fahr DX3.30VFD](#)[Deutz-Fahr DX3.50 \(DX3 Series\)](#)[Deutz-Fahr DX3.50VFD](#)[Deutz-Fahr DX3.90 \(DX3 Series\)](#)[Deutz-Fahr DX4.10 \(DX4 Series\)](#)[Deutz-Fahr DX4.30 \(DX4 Series\)](#)[Deutz-Fahr DX4.50 \(DX4 Series\)](#)[Deutz-Fahr DX4.70 \(DX4 Series\)](#)[Deutz-Fahr DX6.05 \(DX6 Series\)](#)[Deutz-Fahr DX6.10 \(DX6 Series\)](#)[Deutz-Fahr DX6.30 \(DX6 Series\)](#)[Deutz-Fahr DX6.50 \(DX6 Series\)](#)[Deutz-Fahr DX7.10 \(DX7 Series\)](#)[Ford New Holland TV140](#)[Ford New Holland TV145](#)