

Link do produktu: <https://inforolnik.pl/przetyczka-okragla-sworzen-srednica-11mm-x-50mm-ford-new-holland-1252023c91-1252104c91-14710815-224781c1-385159r91-718113012-7704794-81810390-8-p-2177.html>



# Przetyczka okrągła, Sworzeń

## Średnica: 11mm x 50mm ( )

### Ford New Holland

#### 1252023C91 1252104C91

#### 14710815 224781C1

#### 385159R91 718113012

#### 7704794 81810390 8

Cena w sklepie online	<b>4,68 zł</b>
Czas wysyłki	<b>2-3 dni</b>
Numer katalogowy	<b>S.12833</b>

## Opis produktu

Ciężki Funkcja Numery porównawcze: 1252023C91 1252104C91 14710815 224781C1 385159R91 718113012 7704794 81810390 81826837 82000108 82004740 82004771 83902702 87473448 87766398 87768011 A29105 A33509 D129893 D5NND817A E27N995216 E27N995217 K127200 K158100 K161400 UK4604 UK743 UK744 UK786

## Zastosowanie

Kliknij i zobacz inne części które również pasują do : [Case IH 55JXMC](#)[Case IH 65JXMC](#)[Case IH 75JXMC](#)[Case IH 80JXMC](#)[Case IH 90JXMC](#)[Case IH FARMALL 105CC](#)[Case IH FARMALL 110UC](#)[Case IH FARMALL 115CC](#)[Case IH FARMALL 120UC](#)[Case IH FARMALL 45A](#)[Case IH FARMALL 50A](#)[Case IH FARMALL 55A](#)[Case IH FARMALL 85CC](#)[Case IH FARMALL 95CC](#)[Case IH JX55TC](#)[Case IH JX75TC](#)[Case IH JXU 105](#)[Case IH JXU 115](#)[Case IH JXU 75](#)[Case IH JXU 85](#)[Case IH JXU 95](#)[Case IH LUXXUM 100](#)[Case IH LUXXUM 110](#)[Case IH LUXXUM 120](#)[Case IH MAXXUM 100 - LIMITED](#)[Case IH MAXXUM 100 - VALUE](#)[Case IH MAXXUM 100 - X-LINE](#)[Case IH MAXXUM 110 - CVT](#)[Case IH MAXXUM 110 - CVX](#)[Case IH MAXXUM 110 - GARU](#)[Case IH MAXXUM 110 - LIMITED](#)[Case IH MAXXUM 110 - PRO](#)[Case IH MAXXUM 110 - VALUE](#)[Case IH MAXXUM 110 - X-LINE](#)[Case IH MAXXUM 115 - GARU](#)[Case IH MAXXUM 115 - LIMITED](#)[Case IH MAXXUM 115 - PRO](#)[Case IH MAXXUM 115 - VALUE](#)[Case IH MAXXUM 115 - X-LINE](#)[Case IH MAXXUM 120 - CVT](#)[Case IH MAXXUM 120 - CVX](#)[Case IH MAXXUM 120 - GARU](#)[Case IH MAXXUM 120 - PRO](#)[Case IH MAXXUM 125 - GARU](#)[Case IH MAXXUM 125 - LIMITED](#)[Case IH MAXXUM 125 - PRO](#)[Case IH MAXXUM 125 - VALUE](#)[Case IH MAXXUM 125 - X-LINE](#)[Case IH MAXXUM 130 - CVT](#)[Case IH MAXXUM 130 - CVX](#)[Case IH MAXXUM 130 - GARU](#)[Case IH MAXXUM 130 - PRO](#)[Case IH MAXXUM 140 - GARU](#)[Case IH MAXXUM 140 - LIMITED](#)[Case IH MAXXUM 140 - PRO](#)[Case IH MAXXUM 140 - X-LINE](#)[Case IH MXU100 - VALUE](#)[Case IH MXU100 \(MXU Series\)](#)[Case IH MXU110 - X-LINE](#)[Case IH MXU110 \(MXU Series\)](#)[Case IH MXU115 - X-LINE](#)[Case IH MXU115 \(MXU Series\)](#)[Case IH MXU125 \(MXU Series\)](#)[Case IH MXU130 - X-LINE](#)[Case IH MXU135 \(MXU Series\)](#)[Case IH PUMA 125 - GARU](#)[Case IH PUMA 140 - GARU](#)[Case IH PUMA 155 - GARU](#)[Case IH PUMA 1654](#)[Case IH PUMA 1804](#)[Ford New Holland 340 \(Industrial\)](#)[Ford New Holland 3600 \(100 Series\)](#)[Ford New Holland 3630](#)[Ford New Holland 445 \(Industrial\)](#)[Ford New Holland 4500 \(Industrial\)](#)[Ford New Holland 455 \(Backhoe\)](#)[Ford New Holland 540 \(Industrial\)](#)[Ford New Holland 545 \(Industrial\)](#)[Ford New Holland 5500 \(Backhoe\)](#)[Ford New Holland 555 \(Backhoe\)](#)[Ford New Holland 5630](#)[Ford New Holland 575 \(Backhoe\)](#)[Ford New Holland 6500 \(Backhoe\)](#)[Ford New Holland 655 \(Backhoe\)](#)[Ford New Holland 6610S](#)[Ford New Holland 7500 \(Backhoe\)](#)[Ford New Holland 755 \(Backhoe\)](#)[Ford New Holland 7610S](#)[Ford New Holland T1804B](#)[Ford New Holland T4.105](#)[Ford New Holland T4.105LP](#)[Ford New Holland T4.115](#)[Ford New Holland T4.75](#)[Ford New Holland T4.75LP](#)[Ford New Holland T4.85](#)[Ford New Holland T4.85LP](#)[Ford New Holland T4.95](#)[Ford New Holland T4.95LP](#)[Ford New Holland T5.100 - ELECTRO COMMAND](#)[Ford New Holland T5.105 - ELECTRO COMMAND](#)[Ford New Holland T5.110 - ELECTRO COMMAND](#)[Ford New Holland T5.115 - ELECTRO COMMAND](#)[Ford New Holland T5.120 - ELECTRO COMMAND](#)[Ford New Holland T5.95 - ELECTRO COMMAND](#)[Ford New Holland T5030 \(T5000 Series\)](#)[Ford New Holland T5040 \(T5000 Series\)](#)[Ford New Holland T5050 \(T5000 Series\)](#)[Ford New Holland T5060 \(T5000 Series\)](#)[Ford New Holland](#)

**Account for EURO PAYMENTS:**

PL78 1140 2004 0000 3812 0242 0461

Bic ( IBAN ) : BREXPLPWMBK

---

[T5070 \(T5000 Series\)](#)[Ford New Holland T6.120 \(T6 Series\)](#)[Ford New Holland T6.140 - AUTOCOMMAND](#)[Ford New Holland T6.140 \(T6 Series\)](#)[Ford New Holland T6.150 - AUTOCOMMAND](#)[Ford New Holland T6.150 \(T6 Series\)](#)[Ford New Holland T6.155 \(T6 Series\)](#)[Ford New Holland T6.160 - AUTOCOMMAND](#)[Ford New Holland T6.160 \(T6 Series\)](#)[Ford New Holland T6.165 \(T6 Series\)](#)[Ford New Holland T6.175 \(T6 Series\)](#)[Ford New Holland T6010 - DELTA](#)[Ford New Holland T6010 - PLUS](#)[Ford New Holland T6020 - DELTA](#)[Ford New Holland T6020 - ELITE](#)[Ford New Holland T6020 - PLUS](#)[Ford New Holland T6030 - DELTA](#)[Ford New Holland T6030 - ELITE](#)[Ford New Holland T6030 - PLUS](#)[Ford New Holland T6030 - POWER COMMAND](#)[Ford New Holland T6030 - RANGE COMMAND](#)[Ford New Holland T6040 - ELITE](#)[Ford New Holland T6050 - DELTA](#)[Ford New Holland T6050 - ELITE](#)[Ford New Holland T6050 - PLUS](#)[Ford New Holland T6050 - POWER COMMAND](#)[Ford New Holland T6050 - RANGE COMMAND](#)[Ford New Holland T6060 - ELITE](#)[Ford New Holland T6070 - ELITE](#)[Ford New Holland T6070 - PLUS](#)[Ford New Holland T6070 - POWER COMMAND](#)[Ford New Holland T6070 - RANGE COMMAND](#)[Ford New Holland T6080 - POWER COMMAND](#)[Ford New Holland T6080 - RANGE COMMAND](#)[Ford New Holland T6090 - POWER COMMAND](#)[Ford New Holland T6090 - RANGE COMMAND](#)[Ford New Holland TL65 \(TL Series\)](#)[Ford New Holland TS100 BRAZILIAN](#)[Ford New Holland TS100A](#)[Ford New Holland TS110 BRAZILIAN](#)[Ford New Holland TS110A](#)[Ford New Holland TS115A](#)[Ford New Holland TS120 BRAZILIAN](#)[Ford New Holland TS125A](#)[Ford New Holland TS135A](#)[Ford New Holland TT35](#)[Ford New Holland TT4.55](#)[Ford New Holland TT4.75](#)[Ford New Holland TT4.80](#)[Ford New Holland TT4.90](#)[Ford New Holland TT40](#)[Ford New Holland TT45](#)[Ford New Holland TT50](#)[Ford New Holland TT55](#)[Ford New Holland TT65](#)[Ford New Holland TT75](#)[Steyr 4075 KOMPAKT](#)[Steyr 4085 KOMPAKT](#)[Steyr 4095 KOMPAKT](#)[Steyr 4095 MULTI](#)[Steyr 4100 MULTI](#)[Steyr 4100 Profi \(Profi Series\)](#)[Steyr 4105 KOMPAKT](#)[Steyr 4105 MULTI](#)[Steyr 4110 MULTI](#)[Steyr 4110 PROF](#)[Steyr 4115 KOMPAKT](#)[Steyr 4115 MULTI](#)[Steyr 4115 Profi \(Profi Series\)](#)[Steyr 4120 MULTI](#)[Steyr 4120 PROF](#)[Steyr 4130 PROF](#)[Steyr 6115 Profi \(Profi Series\)](#)[Steyr 6125 Profi \(Profi Series\)](#)[Steyr 6135 Profi \(Profi Series\)](#)[Steyr 6140 PROF](#)