

Link do produktu: <https://inforolnik.pl/tuleja-case-ih-358958r1-358958r2-367099r1-376099r1-p-16116.html>



# Tuleja Case IH 358958R1 358958R2 367099R1 376099R1

Cena w sklepie online **16,88 zł**

Czas wysyłki **2-3 dni**

Numer katalogowy **S.17473**

## Opis produktu

Wymiar wrzeciona 42.25 x 46.3 x 50.9mm Numery porównawcze: 358958R1 358958R2 367099R1 376099R1

## Zastosowanie

Kliknij i zobacz inne części które również pasują do : [Case IH 1026 \(International\)](#)[Case IH 1066 \(66 Series\)](#)[Case IH 1086 \(86 Series\)](#)[Case IH 1206 \(Industrial\)](#)[Case IH 1256 \(56 Series\)](#)[Case IH 1456 \(56 Series\)](#)[Case IH 1486 \(86 Series\)](#)[Case IH 1586 \(86 Series\)](#)[Case IH 186](#)[Case IH 21206 \(Industrial\)](#)[Case IH 21256 \(Industrial\)](#)[Case IH 21456 \(International\)](#)[Case IH 238 \(Industrial\)](#)[Case IH 2404 \(Industrial\)](#)[Case IH 2424 \(Industrial\)](#)[Case IH 2444 \(Industrial\)](#)[Case IH 248 \(Industrial\)](#)[Case IH 2504 \(Industrial\)](#)[Case IH 2544 \(Industrial\)](#)[Case IH 258 \(Industrial\)](#)[Case IH 2606 \(Industrial\)](#)[Case IH 2656 \(Industrial\)](#)[Case IH 268 \(Industrial\)](#)[Case IH 2706 \(Industrial\)](#)[Case IH 2756 \(Industrial\)](#)[Case IH 2806 \(Industrial\)](#)[Case IH 2826 \(Industrial\)](#)[Case IH 2856 \(Industrial\)](#)[Case IH 288 \(Industrial\)](#)[Case IH 300 \(Farmall Series\)](#)[Case IH 300 \(International\)](#)[Case IH 3088 \(30 Series\)](#)[Case IH 3210 \(3200 Utility Series \)](#)[Case IH 3220 \(3200 Utility Series \)](#)[Case IH 3230 \(32 Series\)](#)[Case IH 3288 \(30 Series\)](#)[Case IH 330 \(International\)](#)[Case IH 340 \(40 Series\)](#)[Case IH 340 \(Farmall Series\)](#)[Case IH 3488 \(30 Series\)](#)[Case IH 350 \(Farmall Series\)](#)[Case IH 350 \(International\)](#)[Case IH 3688 \(30 Series\)](#)[Case IH 385 \(85 Series\)](#)[Case IH 395 \(95 Utility Series \)](#)[Case IH 404 \(International\)](#)[Case IH 4210 \(4200 Utility Series\)](#)[Case IH 4220 \(4200 Utility Series\)](#)[Case IH 4230 \(4200 Utility Series\)](#)[Case IH 4240 \(4200 Utility Series\)](#)[Case IH 454 \(International\)](#)[Case IH 460 \(60 Series\)](#)[Case IH 474 \(International\)](#)[Case IH 475 \(International\)](#)[Case IH 484 \(International\)](#)[Case IH 485 \(85 Series\)](#)[Case IH 485XL](#)[Case IH 495 \(95 Utility Series \)](#)[Case IH 495XL](#)[Case IH 504 \(International\)](#)[Case IH 5088 \(50 Series\)](#)[Case IH 5288 \(50 Series\)](#)[Case IH 544 \(International\)](#)[Case IH 5488 \(50 Series\)](#)[Case IH 560 \(Farmall Series\)](#)[Case IH 574 \(74 Series\)](#)[Case IH 584 \(84 Series\)](#)[Case IH 585 \(85 Utility Series\)](#)[Case IH 585XL](#)[Case IH 595 \(95 Utility Series \)](#)[Case IH 595XL](#)[Case IH 606 \(International\)](#)[Case IH 656 \(56 Series\)](#)[Case IH 656 \(International\)](#)[Case IH 660 \(60 Series\)](#)[Case IH 660 \(Farmall Series\)](#)[Case IH 664 \(International\)](#)[Case IH 666 \(66 Series\)](#)[Case IH 674 \(Utility Series\)](#)[Case IH 684 \(84 Series\)](#)[Case IH 685 \(85 Series\)](#)[Case IH 685XL](#)[Case IH 686 \(86 Series\)](#)[Case IH 695 \(95 Utility Series \)](#)[Case IH 695XL](#)[Case IH 706 \(Farmall Series\)](#)[Case IH 706 \(International\)](#)[Case IH 756 \(56 Series\)](#)[Case IH 756 \(Farmall Series\)](#)[Case IH 766 \(66 Series\)](#)[Case IH 784 \(84 Series\)](#)[Case IH 784 \(International\)](#)[Case IH 785 \(85 Series\)](#)[Case IH 785 \(International\)](#)[Case IH 785XL](#)[Case IH 786 \(86 Series\)](#)[Case IH 795 \(95 Utility Series \)](#)[Case IH 795XL](#)[Case IH 806 \(Farmall Series\)](#)[Case IH 806 \(International\)](#)[Case IH 826 \(Farmall Series\)](#)[Case IH 826 \(International\)](#)[Case IH 856 \(56 Series\)](#)[Case IH 884 \(84 Series\)](#)[Case IH 885 \(85 Series\)](#)[Case IH 885XL](#)[Case IH 886 \(86 Series\)](#)[Case IH 895 \(95 Utility Series \)](#)[Case IH 895XL](#)[Case IH 966 \(66 Series\)](#)[Case IH 986 \(86 Series\)](#)[Case IH 995 \(95 Utility Series \)](#)[Case IH 995XL](#)[Case IH C50 \(C Series\)](#)[Case IH C60 \(C Series\)](#)[Case IH C70 \(C Series\)](#)[Case IH C80 \(C Series\)](#)[Case IH C90 \(C Series\)](#)[Case IH CX100 \(CX Series\)](#)[Case IH CX50 \(CX Series\)](#)[Case IH CX60 \(CX Series\)](#)[Case IH CX70 \(CX Series\)](#)[Case IH CX80 \(CX Series\)](#)[Case IH CX90 \(CX Series\)](#)[Case IH Hydro 84 \(Hydro Static Drive Tractors\)](#)[Case IH Hydro 86 \(Hydro Static Drive Tractors\)](#)[Case IH MX100C](#)[Case IH MX80C](#)[Case IH MX90C](#)[McCormick CX100 \(CX Series\)](#)[McCormick CX50 \(CX Series\)](#)[McCormick CX60 \(CX Series\)](#)[McCormick CX70 \(CX Series\)](#)[McCormick CX80 \(CX Series\)](#)[McCormick CX90 \(CX Series\)](#)