

Link do produktu: <https://inforolnik.pl/tuleja-fiat-ford-new-holland-5101112-p-16067.html>



Tuleja Fiat Ford New Holland 5101112

Cena w sklepie online **38,00 zł**

Czas wysyłki **2-3 dni**

Numer katalogowy **S.62839**

Opis produktu

Wymiar wrzeciona 52.9 x 57.1 x 41.83mm Numery porównawcze: 5101112

Zastosowanie

Kliknij i zobacz inne części które również pasują do : [Allis Chalmers 6060](#)[Allis Chalmers 6070](#)[Allis Chalmers 6080](#)[Case IH 55JXM](#)[Case IH 65JXM](#)[Case IH 75JXM](#)[Case IH 80JXM](#)[Case IH 90JXM](#)[Case IH AVJ55 \(AVJ Series\)](#)[Case IH AVJ60 \(AVJ Series\)](#)[Case IH AVJ70 \(AVJ Series\)](#)[Case IH FARMALL 105A](#)[Case IH FARMALL 105A - TMRC](#)[Case IH FARMALL 105CC](#)[Case IH FARMALL 110U](#)[Case IH FARMALL 115A](#)[Case IH FARMALL 115C](#)[Case IH FARMALL 120U](#)[Case IH FARMALL 45A](#)[Case IH FARMALL 50A](#)[Case IH FARMALL 55A](#)[Case IH FARMALL 55C](#)[Case IH FARMALL 65A](#)[Case IH FARMALL 65C](#)[Case IH FARMALL 75A](#)[Case IH FARMALL 75C](#)[Case IH FARMALL 85A](#)[Case IH FARMALL 85A - TMRC](#)[Case IH FARMALL 85C](#)[Case IH FARMALL 95A](#)[Case IH FARMALL 95A - TMRC](#)[Case IH FARMALL 95C](#)[Case IH FARMALL JX70](#)[Case IH FARMALL JX80](#)[Case IH JX100U](#)[Case IH JX1060C](#)[Case IH JX1070C](#)[Case IH JX1075C](#)[Case IH JX1080U](#)[Case IH JX1085C](#)[Case IH JX1090U](#)[Case IH JX1095C](#)[Case IH JX1100U](#)[Case IH JX55 \(JX Series\)](#)[Case IH JX55TC](#)[Case IH JX60 \(JX Series\)](#)[Case IH JX65 \(JX Series\)](#)[Case IH JX70 \(JX Series\)](#)[Case IH JX70U](#)[Case IH JX75 \(JX Series\)](#)[Case IH JX75TC](#)[Case IH JX80 \(JX Series\)](#)[Case IH JX80U](#)[Case IH JX85 \(JX Series\)](#)[Case IH JX90 \(JX Series\)](#)[Case IH JX90U](#)[Case IH JX95 \(JX Series\)](#)[Case IH JXU 105](#)[Case IH JXU 115](#)[Case IH JXU 75](#)[Case IH JXU 85](#)[Case IH JXU 95](#)[Case IH LUXXUM 100](#)[Case IH LUXXUM 110](#)[Case IH LUXXUM 120](#)[Case IH MAXXUM 100 - LIMITED](#)[Case IH MAXXUM 100 - VALUE](#)[Case IH MAXXUM 100 - X-LINE](#)[Case IH MAXXUM 110 - CVT](#)[Case IH MAXXUM 110 - CVX](#)[Case IH MAXXUM 110 - GARU](#)[Case IH MAXXUM 110 - LIMITED](#)[Case IH MAXXUM 110 - PROC](#)[Case IH MAXXUM 110 - VALUE](#)[Case IH MAXXUM 110 - X-LINE](#)[Case IH Maxxum 115 \(Maxxum Series\)](#)[Case IH MAXXUM 120 - CVT](#)[Case IH MAXXUM 120 - CVX](#)[Case IH MAXXUM 120 - GARU](#)[Case IH MAXXUM 120 - PROC](#)[Case IH MAXXUM 125 - CVT](#)[Case IH MAXXUM 125 - CVX](#)[Case IH MAXXUM 125 - GARU](#)[Case IH MAXXUM 125 - LIMITED](#)[Case IH MAXXUM 125 - PROC](#)[Case IH MAXXUM 125 - VALUE](#)[Case IH MAXXUM 125 - X-LINE](#)[Case IH Maxxum 125 \(Maxxum Series\)](#)[Case IH MAXXUM 130 - CVT](#)[Case IH MAXXUM 130 - CVX](#)[Case IH MAXXUM 130 - GARU](#)[Case IH MAXXUM 130 - PROC](#)[Case IH MAXXUM 135](#)[Case IH MAXXUM 135 - CVT](#)[Case IH MAXXUM 135 - CVX](#)[Case IH MAXXUM 140 - GARU](#)[Case IH MAXXUM 140 - LIMITED](#)[Case IH MAXXUM 140 - PROC](#)[Case IH MAXXUM 140 - X-LINE](#)[Case IH MAXXUM 145](#)[Case IH MAXXUM 145 - CVT](#)[Case IH MAXXUM 145 - CVX](#)[Case IH MAXXUM 150](#)[Case IH MAXXUM 150 - CVX](#)[Case IH MXM120 \(MXM Series\)](#)[Case IH MXM130 \(MXM Series\)](#)[Case IH MXM140 \(MXM Series\)](#)[Case IH MXU100 - VALUE](#)[Case IH MXU100 \(MXU Series\)](#)[Case IH MXU110 - X-LINE](#)[Case IH MXU110 \(MXU Series\)](#)[Case IH MXU115 - X-LINE](#)[Case IH MXU115 \(MXU Series\)](#)[Case IH MXU125 \(MXU Series\)](#)[Case IH MXU130 - X-LINE](#)[Case IH MXU135 \(MXU Series\)](#)[Case IH Puma 115 \(Puma Series\)](#)[Case IH PUMA 125 - GARU](#)[Case IH Puma 125 \(Puma Series\)](#)[Case IH PUMA 130 - CVT](#)[Case IH PUMA 130 - CVX](#)[Case IH Puma 130 \(Puma Series\)](#)[Case IH PUMA 140 - GARU](#)[Case IH Puma 140 \(Puma Series\)](#)[Case IH PUMA 145 - CVT](#)[Case IH PUMA 145 - CVX](#)[Case IH Puma 145 \(Puma Series\)](#)[Case IH PUMA 150](#)[Case IH PUMA 150 - CVT](#)[Case IH PUMA 150 - CVX](#)[Case IH PUMA 155 - GARU](#)[Case IH Puma 155 \(Puma Series\)](#)[Case IH PUMA 160](#)[Case IH PUMA 160 - CVT](#)[Case IH PUMA 160 - CVX](#)[Case IH PUMA 165 - CVT](#)[Case IH PUMA 165 - CVX](#)[Case IH Puma 165 \(Puma Series\)](#)[Case IH PUMA 1654](#)[Case IH PUMA 175 - CVX](#)[Case IH PUMA 1804](#)[Case IH QUANTUM 100CL](#)[Case IH QUANTUM 110CL](#)[Case IH QUANTUM 65C](#)[Case IH QUANTUM 75C](#)[Case IH QUANTUM 80CL](#)[Case IH QUANTUM 85C](#)[Case IH QUANTUM 90CL](#)[Case IH QUANTUM 95C](#)[Case IH VJ60 \(VJ Series\)](#)[Case IH VJ70 \(VJ Series\)](#)[Case IH VJ80 \(VJ Series\)](#)[Fiat 100-90 \(90 Series\)](#)[Fiat 110-90 \(90 Series\)](#)[Fiat 115-90 \(90 Series\)](#)[Fiat 1180 \(Classic Models\)](#)[Fiat 1280 \(Classic Models\)](#)[Fiat 130-90 \(90 Series\)](#)[Fiat 1380 \(Classic Models\)](#)[Fiat 140-90 \(90 Series\)](#)[Fiat 1580 \(Classic Models\)](#)[Fiat 160-90 \(90 Series\)](#)[Fiat 180-90 \(90 Series\)](#)[Fiat 1880 \(Classic Models\)](#)[Fiat 446 \(Classic Models\)](#)[Fiat 45-66 \(66 Series\)](#)[Fiat 466 \(Classic Models\)](#)[Fiat 50-66 \(66 Series\)](#)[Fiat 55-46 \(46 Series\)](#)[Fiat 55-56 \(56 Series\)](#)[Fiat 55-66 \(66 Series\)](#)[Fiat 55-76 \(76 Series\)](#)[Fiat 55-86 \(86 Series\)](#)[Fiat 55-88 \(88 Series\)](#)[Fiat 55-90 \(90 Series\)](#)[Fiat 566 \(Classic Models\)](#)[Fiat 580 \(Classic Models\)](#)[Fiat 60-46 \(46 Series\)](#)[Fiat 60-56 \(56 Series\)](#)[Fiat](#)

Account for EURO PAYMENTS:

PL78 1140 2004 0000 3812 0242 0461

Bic (IBAN) : BREXPLPWMBK

[60-66 \(66 Series\)](#)[Fiat 60-76 \(76 Series\)](#)[Fiat 60-86 \(86 Series\)](#)[Fiat 60-88 \(88 Series\)](#)[Fiat 60-90 \(90 Series\)](#)[Fiat 60-93 \(93 Series \)](#)[Fiat 60-94 \(94 Series\)](#)[Fiat 62-86 \(86 Series\)](#)[Fiat 65-46 \(46 Series\)](#)[Fiat 65-56 \(56 Series\)](#)[Fiat 65-88 \(88 Series\)](#)[Fiat 65-90 \(90 Series\)](#)[Fiat 65-93 \(93 Series \)](#)[Fiat 65-94 \(94 Series\)](#)[Fiat 666 \(Classic Models\)](#)[Fiat 680 \(Classic Models\)](#)[Fiat 70-56 \(56 Series\)](#)[Fiat 70-76 \(76 Series\)](#)[Fiat 70-86 \(86 Series\)](#)[Fiat 70-88 \(88 Series\)](#)[Fiat 70-90 \(90 Series\)](#)[Fiat 72-86 \(86 Series\)](#)[Fiat 72-93 \(93 Series \)](#)[Fiat 72-94 \(94 Series\)](#)[Fiat 766 \(Classic Models\)](#)[Fiat 780 \(Classic Models\)](#)[Fiat 80-76 \(76 Series\)](#)[Fiat 80-88 \(88 Series\)](#)[Fiat 80-90 \(90 Series\)](#)[Fiat 82-86 \(86 Series\)](#)[Fiat 82-86 \(86 Series\)](#)[Fiat 82-93 \(93 Series \)](#)[Fiat 82-94 \(94 Series\)](#)[Fiat 85-90 \(90 Series\)](#)[Fiat 880 \(Classic Models\)](#)[Fiat 88-93 \(93 Series \)](#)[Fiat 88-94 \(94 Series\)](#)[Fiat 90-90 \(90 Series\)](#)[Fiat 980 \(Classic Models\)](#)[Fiat F100 \(F Series\)](#)[Fiat F110 \(F Series\)](#)[Fiat F115 \(F Series\)](#)[Fiat L60 \(L Series\)](#)[Fiat L75 \(L Series\)](#)[Fiat L85 \(L Series\)](#)[Fiat L95 \(L Series\)](#)[Fiat M100 \(M Series\)](#)[Fiat M115 \(M Series\)](#)[Ford New Holland 3010S](#)[Ford New Holland 3435 \(35 Series \)](#)[Ford New Holland 3600 \(100 Series\)](#)[Ford New Holland 3630](#)[Ford New Holland 3830 \(30 Series\)](#)[Ford New Holland 3935 \(35 Series \)](#)[Ford New Holland 4010S](#)[Ford New Holland 4030 \(30 Series\)](#)[Ford New Holland 4135 \(35 Series \)](#)[Ford New Holland 4230 \(30 Series\)](#)[Ford New Holland 4430 \(30 Series\)](#)[Ford New Holland 4635 \(35 Series \)](#)[Ford New Holland 4835 \(35 Series \)](#)[Ford New Holland 5010S](#)[Ford New Holland 5500 \(Backhoe\)](#)[Ford New Holland 5630](#)[Ford New Holland 5635 \(35 Series \)](#)[Ford New Holland 5640 \(40 Series\)](#)[Ford New Holland 6500 \(Backhoe\)](#)[Ford New Holland 6635 \(35 Series \)](#)[Ford New Holland 6640 \(40 Series\)](#)[Ford New Holland 7500 \(Backhoe\)](#)[Ford New Holland 7635 \(35 Series \)](#)[Ford New Holland 7740 \(40 Series\)](#)[Ford New Holland 7840 \(40 Series\)](#)[Ford New Holland 8160 \(60 Series \)](#)[Ford New Holland 8240 \(40 Series\)](#)[Ford New Holland 8260 \(60 Series \)](#)[Ford New Holland 8340 \(40 Series\)](#)[Ford New Holland T1804B](#)[Ford New Holland T3.50](#)[Ford New Holland T3.55](#)[Ford New Holland T3.60](#)[Ford New Holland T3.65](#)[Ford New Holland T3.70](#)[Ford New Holland T3.75](#)[Ford New Holland T3.80](#)[Ford New Holland T4.100LP](#)[Ford New Holland T4.105](#)[Ford New Holland T4.110LP](#)[Ford New Holland T4.115](#)[Ford New Holland T4.55](#)[Ford New Holland T4.55S](#)[Ford New Holland T4.65](#)[Ford New Holland T4.65S](#)[Ford New Holland T4.75](#)[Ford New Holland T4.75S](#)[Ford New Holland T4.80LP](#)[Ford New Holland T4.85](#)[Ford New Holland T4.90LP](#)[Ford New Holland T4.95](#)[Ford New Holland T4020](#)[Ford New Holland T4030](#)[Ford New Holland T4040](#)[Ford New Holland T4050](#)[Ford New Holland T5.100 - ELECTRO COMMAND](#)[Ford New Holland T5.105](#)[Ford New Holland T5.105 - DUAL COMMAND](#)[Ford New Holland T5.105 - ELECTRO COMMAND](#)[Ford New Holland T5.105 - POWER SHUTTLE](#)[Ford New Holland T5.110 - ELECTRO COMMAND](#)[Ford New Holland T5.115](#)[Ford New Holland T5.115 - DUAL COMMAND](#)[Ford New Holland T5.115 - ELECTRO COMMAND](#)[Ford New Holland T5.115 - POWER SHUTTLE](#)[Ford New Holland T5.120 - ELECTRO COMMAND](#)[Ford New Holland T5.75 - DUAL COMMAND](#)[Ford New Holland T5.75 - MECHANICAL](#)[Ford New Holland T5.75 - POWER SHUTTLE](#)[Ford New Holland T5.85 - DUAL COMMAND](#)[Ford New Holland T5.85 - MECHANICAL](#)[Ford New Holland T5.85 - POWER SHUTTLE](#)[Ford New Holland T5.95](#)[Ford New Holland T5.95 - DUAL COMMAND](#)[Ford New Holland T5.95 - ELECTRO COMMAND](#)[Ford New Holland T5.95 - MECHANICAL](#)[Ford New Holland T5.95 - POWER SHUTTLE](#)[Ford New Holland T5030 \(T5000 Series\)](#)[Ford New Holland T5040 \(T5000 Series\)](#)[Ford New Holland T5050 \(T5000 Series\)](#)[Ford New Holland T5060 \(T5000 Series\)](#)[Ford New Holland T5070 \(T5000 Series\)](#)[Ford New Holland T6.120 \(T6 Series\)](#)[Ford New Holland T6.125](#)[Ford New Holland T6.140 - AUTOCOMMAND](#)[Ford New Holland T6.140 \(T6 Series\)](#)[Ford New Holland T6.145](#)[Ford New Holland T6.145 - AUTOCOMMAND](#)[Ford New Holland T6.145 - DUAL CLUTCH](#)[Ford New Holland T6.150 - AUTOCOMMAND](#)[Ford New Holland T6.150 \(T6 Series\)](#)[Ford New Holland T6.155 - AUTOCOMMAND](#)[Ford New Holland T6.155 - DUAL CLUTCH](#)[Ford New Holland T6.155 \(T6 Series\)](#)[Ford New Holland T6.160 - AUTOCOMMAND](#)[Ford New Holland T6.160 \(T6 Series\)](#)[Ford New Holland T6.165 - AUTOCOMMAND](#)[Ford New Holland T6.165 \(T6 Series\)](#)[Ford New Holland T6.175 - AUTOCOMMAND](#)[Ford New Holland T6.175 - DUAL CLUTCH](#)[Ford New Holland T6.175 \(T6 Series\)](#)[Ford New Holland T6.180](#)[Ford New Holland T6.180 - AUTOCOMMAND](#)[Ford New Holland T6.180 - DUAL CLUTCH](#)[Ford New Holland T6010 - DELTA](#)[Ford New Holland T6010 - PLUS](#)[Ford New Holland T6020 - DELTA](#)[Ford New Holland T6020 - ELITE](#)[Ford New Holland T6020 - PLUS](#)[Ford New Holland T6030 - DELTA](#)[Ford New Holland T6030 - ELITE](#)[Ford New Holland T6030 - PLUS](#)[Ford New Holland T6030 - POWER COMMAND](#)[Ford New Holland T6030 - RANGE COMMAND](#)[Ford New Holland T6040 - ELITE](#)[Ford New Holland T6050 - DELTA](#)[Ford New Holland T6050 - ELITE](#)[Ford New Holland T6050 - PLUS](#)[Ford New Holland T6050 - POWER COMMAND](#)[Ford New Holland T6050 - RANGE COMMAND](#)[Ford New Holland T6060 - ELITE](#)[Ford New Holland T6070 - ELITE](#)[Ford New Holland T6070 - PLUS](#)[Ford New Holland T6070 - POWER COMMAND](#)[Ford New Holland T6070 - RANGE COMMAND](#)[Ford New Holland T6080 - POWER COMMAND](#)[Ford New Holland T6080 - RANGE COMMAND](#)[Ford New Holland T6090 - POWER COMMAND](#)[Ford New Holland T6090 - RANGE COMMAND](#)[Ford New Holland T7.165 - CLASSIC](#)[Ford New Holland T7.165S - CLASSIC](#)[Ford New Holland T7.170 - AUTOCOMMAND](#)[Ford New Holland T7.170 - POWER COMMAND](#)[Ford New Holland T7.170 - RANGE COMMAND](#)[Ford New Holland T7.175](#)[Ford New Holland T7.175 - AUTOCOMMAND](#)[Ford New Holland T7.175 - CLASSIC](#)[Ford New Holland T7.175 - SIDEWINDER II](#)[Ford New Holland T7.185 - AUTOCOMMAND](#)[Ford New Holland T7.185 - POWER COMMAND](#)[Ford New Holland T7.185 - RANGE COMMAND](#)[Ford New Holland T7.190](#)[Ford New Holland T7.190 - AUTOCOMMAND](#)[Ford New Holland T7.190 - CLASSIC](#)[Ford New Holland T7.190 - SIDEWINDER II](#)[Ford New Holland T7.200 - AUTOCOMMAND](#)[Ford New Holland T7.200 - POWER COMMAND](#)[Ford New Holland T7.200 - RANGE COMMAND](#)[Ford New Holland T7.210 - AUTOCOMMAND](#)[Ford New Holland T7.210 - CLASSIC](#)[Ford New Holland T7.210 - POWER COMMAND](#)[Ford New Holland T7.210 - RANGE COMMAND](#)[Ford New Holland T7.210 - SIDEWINDER II](#)[Ford New Holland T7.210 \(T7 Series\)](#)[Ford New Holland T7.225 - AUTOCOMMAND](#)[Ford New Holland TD3.50](#)[Ford New Holland TD4.100](#)[Ford New Holland TD4.70](#)[Ford New Holland TD4.80](#)[Ford New Holland TD4.90](#)[Ford New Holland TD4020](#)[Ford New Holland TD4030](#)[Ford New Holland TD4040](#)[Ford New Holland TD5.100](#)[Ford New Holland TD5.105](#)[Ford New Holland TD5.110](#)[Ford New Holland TD5.115](#)[Ford New Holland TD5.65](#)[Ford New Holland TD5.75](#)[Ford New Holland TD5.80](#)[Ford New Holland TD5.85](#)[Ford New Holland TD5.90](#)[Ford New Holland TD5.95](#)[Ford New Holland TD5010](#)[Ford New Holland TD5020](#)[Ford New Holland TD5030](#)[Ford New Holland TD5040](#)[Ford New Holland TD5050](#)[Ford New Holland TD55D](#)[Ford New Holland TD60 \(TD Series\)](#)[Ford New Holland TD60D](#)[Ford New Holland TD65B](#)[Ford New Holland TD65D](#)[Ford New Holland TD65F](#)[Ford New Holland TD70 \(TD Series\)](#)[Ford New Holland TD70D](#)[Ford New Holland TD75D](#)[Ford New Holland TD75F](#)[Ford New Holland TD80 \(TD Series\)](#)[Ford New Holland TD80D](#)[Ford New Holland TD85D](#)[Ford New Holland TD85F](#)[Ford New Holland TD90 \(TD Series\)](#)[Ford New Holland TD90D](#)[Ford New Holland TD95 \(TD Series\)](#)[Ford New Holland TD95D](#)[Ford New Holland TL100 \(TL Series\)](#)[Ford New Holland TL100A](#)[Ford New Holland TL65 \(TL Series\)](#)[Ford New Holland TL70 \(TL Series\)](#)[Ford New Holland TL80 \(TL Series\)](#)[Ford New Holland TL80A](#)[Ford New Holland TL90 \(TL Series\)](#)[Ford New Holland TL90A](#)[Ford New Holland TM110 \(TM Series\)](#)[Ford New Holland TM110 BRAZILIAN](#)[Ford New Holland TM115 \(TM Series\)](#)[Ford New Holland TM120 \(TM Series\)](#)[Ford New Holland TM120 BRAZILIAN](#)[Ford New Holland TM125 \(TM Series\)](#)[Ford New Holland TM130 \(TM Series\)](#)[Ford New Holland TM130 BRAZILIAN](#)[Ford New Holland TM135 \(TM Series\)](#)[Ford New Holland TM135 BRAZILIAN](#)[Ford New Holland TM140 \(TM Series\)](#)[Ford New Holland TN55 \(TN Series\)](#)[Ford New Holland TN55D](#)[Ford New Holland TN60A](#)[Ford New Holland TN60DA](#)[Ford New Holland TN65 \(TN Series\)](#)[Ford New Holland](#)

Account for EURO PAYMENTS:

PL78 1140 2004 0000 3812 0242 0461

Bic (IBAN) : BREXPLPWMBK

[TN65DFord New Holland TN70 \(TN Series\)Ford New Holland TN70AFord New Holland TN70DFord New Holland TN70DAFord New Holland TN75 \(TN Series\)Ford New Holland TN75AFord New Holland TN75DFord New Holland TN75DAFord New Holland TN85AFord New Holland TN85DAFord New Holland TN95AFord New Holland TN95DAFord New Holland TS100 \(TS Series\)Ford New Holland TS100 BRAZILIANFord New Holland TS100AFord New Holland TS110 \(TS Series\)Ford New Holland TS110 BRAZILIANFord New Holland TS110AFord New Holland TS115 \(TS Series\)Ford New Holland TS120 BRAZILIANFord New Holland TS120AFord New Holland TS125AFord New Holland TS130AFord New Holland TS135AFord New Holland TS6000 - \(BRAZIL\)Ford New Holland TS6020 - \(BRAZIL\)Ford New Holland TS6030 - \(BRAZIL\)Ford New Holland TS6040 - \(BRAZIL\)Ford New Holland TS80 \(TS Series\)Ford New Holland TS90 \(TS Series\)Ford New Holland TT35Ford New Holland TT4.55Ford New Holland TT4.75 Ford New Holland TT4.80Ford New Holland TT4.90Ford New Holland TT40Ford New Holland TT45Ford New Holland TT50Ford New Holland TT55Ford New Holland TT65Ford New Holland TT75Ford New Holland W. CL.1.5 FRONT AXLESteyr 360 KOMPAKT Steyr 370 KOMPAKTSteyr 375 KOMPAKTSteyr 4055S KOMPAKTSteyr 4065 KOMPAKTSteyr 4065S KOMPAKTSteyr 4075 KOMPAKTSteyr 4085 KOMPAKTSteyr 4095 KOMPAKTSteyr 4095 MULTISTeyr 4100 MULTISTeyr 4100 Profi \(Profi Series\)Steyr 4105 KOMPAKTSteyr 4105 MULTISTeyr 4110 MULTISTeyr 4110 PROFISTeyr 4115 KOMPAKTSteyr 4115 MULTISTeyr 4115 Profi \(Profi Series\)Steyr 4120 MULTISTeyr 4120 PROFISTeyr 4125 PROFISTeyr 4130 PROFISTeyr 4135 PROFISTeyr 4145 PROFISTeyr 485 KOMPAKTSteyr 495 KOMPAKTSteyr 6115 Profi \(Profi Series\)Steyr 6125 Profi \(Profi Series\)Steyr 6130CVTSteyr 6135 Profi \(Profi Series\)Steyr 6140 PROFISTeyr 6145 PROFISTeyr 6145CVTSteyr 6150CVTSteyr 6160CVTSteyr 6165CVTSteyr 6175CVT](#)