

Link do produktu: <https://inforolnik.pl/zawor-wydechowy-case-ih-145346a1-147074a1-1484194-1484359-153648843-153649319-3802006-3802356-3920868-4895188-4895768-6904927-72197216-75288022-75311-p-20486.html>



# Zawór wydechowy Case IH 145346A1 147074A1 1484194 1484359 153648843 153649319 3802006 3802356 3920868 4895188 4895768 6904927 72197216 75288022 75311

Cena w sklepie online **36,00 zł**

Numer katalogowy **S.59547**

## Opis produktu

Ref.J901607, J920868 Numery porównawcze: 145346A1 147074A1 1484194 1484359 153648843 153649319 3802006 3802356 3920868 4895188 4895768 6904927 72197216 75288022 75311185 76191868 76192070 76193476 D3543245 J802356 J901607 J920868 L5884215

## Zastosowanie

Kliknij i zobacz inne części które również pasują do : [Case IH 1896 \(1000 Series\)](#)[Case IH 2096 \(2000 Series\)](#)[Case IH 5120 \(Maxxum Series\)](#)[Case IH 5130 \(Maxxum Series\)](#)[Case IH 5140 \(Maxxum Series\)](#)[Case IH 5150 \(Maxxum Series\)](#)[Case IH 5220 \(Maxxum Series\)](#)[Case IH 5230 \(Maxxum Series\)](#)[Case IH 5240 \(Maxxum Series\)](#)[Case IH 5250 \(Maxxum Series\)](#)[Case IH 580 \(Industrial\)](#)[Case IH 580 \(Backhoe\)](#)[Case IH FARMALL 110A](#)[Case IH FARMALL 120A](#)[Case IH FARMALL 125A](#)[Case IH FARMALL 140A](#)[Case IH JX1070U](#)[Case IH JX1080U](#)[Case IH JX1085C](#)[Case IH JX1090U](#)[Case IH JX1095C](#)[Case IH JX1100U](#)[Case IH JX90 \(JX Series\)](#)[Case IH JX95 \(JX Series\)](#)[Case IH JXU 105](#)[Case IH JXU 115](#)[Case IH JXU 75](#)[Case IH JXU 85](#)[Case IH JXU 95](#)[Case IH Maxxum 100 \(Maxxum Series\)](#)[Case IH Maxxum 110 \(Maxxum Series\)](#)[Case IH Maxxum 115 \(Maxxum Series\)](#)[Case IH Maxxum 125 \(Maxxum Series\)](#)[Case IH MAXXUM 140](#)[Case IH MX100 \(MX Series\)](#)[Case IH MX110 \(MX Series\)](#)[Case IH MX120 \(MX Series\)](#)[Case IH MX135 \(MX Series\)](#)[Case IH MX150 \(MX Series\)](#)[Case IH MX170 \(MX Series\)](#)[Case IH MXU100 \(MXU Series\)](#)[Case IH MXU110 \(MXU Series\)](#)[Case IH MXU115 \(MXU Series\)](#)[Case IH MXU130 \(MXU Series\)](#)[Case IH QUANTUM 85C](#)[Case IH QUANTUM 95C](#)[Case IH QUANTUM 95F](#)[Case IH QUANTUM 95N](#)[Case IH QUANTUM 95V](#)[Ford New Holland 5610S](#)[Ford New Holland 6610S](#)[Ford New Holland 7610S](#)[Ford New Holland 8610S](#)[Ford New Holland T4.95F](#)[Ford New Holland T4.95LP](#)[Ford New Holland T4.95N](#)[Ford New Holland T4.95V](#)[Ford New Holland T4030](#)[Ford New Holland T4040](#)[Ford New Holland T4050](#)[Ford New Holland T4050F](#)[Ford New Holland T4050V](#)[Ford New Holland T5030 \(T5000 Series\)](#)[Ford New Holland T5040 \(T5000 Series\)](#)[Ford New Holland T5050 \(T5000 Series\)](#)[Ford New Holland T5060 \(T5000 Series\)](#)[Ford New Holland T5070 \(T5000 Series\)](#)[Ford New Holland T6.110 BRAZILIAN](#)[Ford New Holland T6.120 \(T6 Series\)](#)[Ford New Holland T6.125](#)[Ford New Holland T6.140 \(T6 Series\)](#)[Ford New Holland T6010 \(T6000 Series\)](#)[Ford New Holland T6020 \(T6000 Series\)](#)[Ford New Holland T6030 \(T6000 Series\)](#)[Ford New Holland T6050 \(T6000 Series\)](#)[Ford New Holland T6070 \(T6000 Series\)](#)[Ford New Holland TD5040](#)[Ford New Holland TD5050](#)[Ford New Holland TK4050](#)[Ford New Holland TK4060](#)[Ford New Holland TL100A](#)[Ford New Holland TL70A](#)[Ford New Holland TL80A](#)[Ford New Holland TL90A](#)[Ford New Holland TN85A](#)[Ford New Holland TN85DA](#)[Ford New Holland TN85SA](#)[Ford New Holland TN95A](#)[Ford New Holland TN95DA](#)[Ford New Holland TS100A](#)[Ford New Holland TS110A](#)[Ford New Holland TS115A](#)[Ford New Holland TS130A](#)[Steyr 4085 KOMPAKT](#)[Steyr 4095 KOMPAKT](#)[Steyr 4100 Profi \(Profi Series\)](#)[Steyr 4110 PROF](#)[Steyr 485 KOMPAKT](#)[Steyr 495 KOMPAKT](#)[Steyr 6115 Profi \(Profi Series\)](#)[Steyr 6125 Profi \(Profi Series\)](#)[Steyr 6140 PROF](#)